

Toilet Flange Template



1. Getting ready to mark and cut tile around flange using
(Use 3" or 4" side depending on size of flange)



2. Inserting (3" or 4") circular extension into flange



3. Tool is inserted and set flat on flange. Tool's length is designed to clear all bathroom walls and it can swivel 360 degrees and can mark tile from any angle depending on position of tile in relation to flange



4. Tile is laid out and placed flat between 2 arms



5. Top arm is lowered down flat on tile
Tile is marked without measuring



6. Tile is marked without measuring



7. Top arm lifted and mark is complete



8. Perfect cut from 1st time.